## Root, Khan, and the rise of the Skyscraper (Chicago)

## Themes:

The birth of the modern skyscraper
Tensions between architectural and structural expression in buildings
Expression of structure in skyscraper building form
Stiffness in skyscrapers

Chicago 1871-1893



## The Architecture of JOHN WELLBORN ROOT

The business buildings of Burnham & Root were the first tall buildings in which the conditions both of commercial architecture in general and of elevator architecture in particular were recognized and expressed.


-Montgomery Schuyler, 1895


Yes, we made all these buildings together, but they are chiefly his, for he it was who did the designing....


-D. H. Burnham, 15 January 1891














Jenney 1879 Leiter Bldg.








Sullivan's Wainright in St. Louis



































Root




12-15) hardpan Squish-clay hardpan

Montauk Poch Block



















Monadnock


























The (First) Chicago School

Jenney Sullivan Burnham Root

. . .







"The depression that began in the 1930's and was ended ten years later only by a massive program of military procurement was a disaster for the nation as a whole but an absolute and unmitigated calamity for Chicago. It was not only the collapse of the public and private economy; it was the Sophoclean reversal of fortune, from the expansive force of the twenties ... to the impotence and hopelessness of the thirties."

"It was 12 years after WWII ended before a new building would be built in the Chicago CBD."

Chicago 1930-1970, Carl Condit












## Ludwig Mies van der Rohe



cityofchicago.org









Structural Columns


Structural Beams

**Architectural Mullions** 





**Load Path?** 



**Load Path?** 




Marina city














Chicago Civic Center – now the Daley center

citvofchicago.org





citvofchicago.org





citvofchicago.org



John Hancock Building


















Khan
1929-1982












image for academic use only http://www.emporis.com/en/il/lv/?id=203434









marine midland bank









3 Premium for height is largely due to wind loads.







